



1) Connect the Smartduino board to computer via microUSB cable

2) Open Blink Program from **File** → **Examples** → **Basics** → **Blink**




3) Configure the board in **Tools**

- Board should be selected to '**Smartduino Uno 16Mhz**'
- Processor should be selected to '**ATMega328PB**'
- Port should be selected to your connected Smartduino board




If you are unable to find those in menu, there is problem in the Setup

#### 4) Upload the Blink Program



#### 5) Successful Upload will look as follows, check for 'Done Uploading' and 'Thank you'



#### 6) You should see the Blue LED on the board blinking